



INSTALLATION GUIDE

CAP Dry Carbon Fiber Mirror
Covers|2019-2024 C8 Audi
A6/S6/RS6, A7/S7/RS7, A8/S8

Prefer a video walkthrough? [Watch the full installation process here.](#)

CAP Dry Carbon Fiber Mirror Covers|2019-2024 C8 Audi A6/S6/RS6, A7/S7/RS7, A8/S8



ITEMS INCLUDED

- Driver-side pre-preg dry carbon fiber mirror cover
- Passenger-side pre-preg dry carbon fiber mirror cover

TOOLS REQUIRED

- prying tools

IMPORTANT

Use plastic trim tools and work slowly around the mirror glass and housing. Do not force the glass or cover clips. Disconnect any side-assist / warning-light wiring carefully before fully removing components.



INSTALLATION GUIDE

CAP Dry Carbon Fiber Mirror
Covers|2019-2024 C8 Audi
A6/S6/RS6, A7/S7/RS7, A8/S8

1

RELEASE THE MIRROR GLASS

Fold the mirror housing outward for better access. Using plastic pry tools, carefully work around the mirror and release it from the clips



2

RELEASE THE FACTORY COVER

Use the same plastic pry tools to release the factory mirror cover from the lower housing.



3

TRANSFER THE SIDE-ASSIST LIGHT

Transfer the side-assist / warning-light module into the dedicated opening in the dry carbon fiber mirror cover, then reconnect the wiring





INSTALLATION GUIDE

CAP Dry Carbon Fiber Mirror
Covers|2019-2024 C8 Audi
A6/S6/RS6, A7/S7/RS7, A8/S8

4

INSTALL THE CARBON MIRROR COVER

Guide the mirror assembly through the opening in the new carbon mirror cover. Align the cover with the lower mirror housing, then press evenly around the perimeter until the retaining clips click into place.



5

REINSTALL THE MIRROR GLASS

Align the mirror glass with the retaining clips and press evenly until it is fully clipped back into place.





INSTALLATION GUIDE

CAP Dry Carbon Fiber Mirror
Covers | 2019-2024 C8 Audi
A6/S6/RS6, A7/S7/RS7, A8/S8

CAUTION

Confirm the lip is aligned and securely attached before driving.



Both carbon mirror covers are fully clipped into the lower housings.



Mirror glass is fully seated and secure on both sides.



Side-assist / warning-light modules are installed and connected.



Mirror adjustment and warning-light functions operate normally where equipped.



INSTALLATION GUIDE

CAP Dry Carbon Fiber Mirror
Covers|2019-2024 C8 Audi
A6/S6/RS6, A7/S7/RS7, A8/S8

FINAL RESULT

INSTALLATION COMPLETE



Can Auto Performance

THANK YOU FOR YOUR PURCHASE

Thank you for choosing Can Auto Performance. If you have any questions regarding installation, please [contact us.](#)

www.canautoperformance.com